

FILLING THE VARTA FUNSTART FRESHPACK



1. Preparing the battery

Remove all plugs on top of the battery.



2. Exposing the vent

The side breather vent plug needs to be removed prior to filling.



3. Opening the acid pack

The acid pack is opened by cutting off the acid pack nozzle.



4. Attaching the tube supplied

Attach the tube supplied firmly onto the opening of the acid pack.



5. Filling the battery with acid

Pour the acid slowly into the battery. All chambers must be individually and evenly filled.



6. Disposal of the acid pack

The completely empty acid pack is recyclable. (Check with your local recycling provider).



7. Sealing the battery

Seal the battery completely after filling with the battery plugs you removed in step 1. The side vent plug should not be re-inserted.

Tip: You'll find a detailed description in the instruction manual.